




Управление на On/Off



TF24-, ..F24A-


3-позиционно управление



..F24A-SR(-S), ..F24A-SZ(-S)

Пропорционални


..SR: Y = DC 0 ... 10 V ..SZ: Y = DC 0 ... 10 V
 U = DC 2 ... 10 V U = DC 0 ... 10 V



..F24A-MF, ..F24-MFT

Мултифункционални

Y = Управл. сигнал
 U = Измерване на напрежение





Посока на въртене

TF24-

..F24A-

3-позиционни сервомотори



TF24-SR, TF20-SR

LF24-SR

..F24A-SR(-S), ..F24A-SZ(-S)

Пропорционални сервомотори

